



## Shift Knob Installation Guide



### Tools Needed

- Plastic pry tool
- Small flat head screwdriver
- Scissors

## Stock Knob Removal

1. Gently pry and pull up interior trim around shifter, once loose, pull up over shift knob



2. Locate and gently spread the locking collar with a pick tool or small flat head screwdriver



3. Lift shifter boot and knob off as one piece.

4. Flip over the boot and knob , remove collar attaching boot to shift knob, we suggest using a plastic trim tool to avoid damaging leather boot. Slowly work your way around the collar as to not damage the plastic.



5. Once the collar is off, remove the shift knob from the shifter boot.

6. Now install the adapter portion of your DFG shift knob into the boot



7. Line up the top of the boot with the bottom of knob that will be exposed, use the supplied zip tie to fasten the boot to the knob, be sure to smooth out any bunching of materials or undesired pinches, pull zip tie tight and snip off the excess zip tie/



8. Slide assembled boot and shift knob on to shifter shaft and determine desired height.



9. Using the supplied allen wrench tighten the 3 set screws, be sure to evenly tighten the screws.





10. Push down the shift boot and reinstall the shifter trim.



Enjoy your new shift knob!